

## Dräger PSS® 5000 Compressed Air Breathing Apparatus

The Dräger PSS® 5000 SCBA is a new generation high performance breathing apparatus for the professional firefighter. Combining advanced ergonomics with a wide range of configurable options the Dräger PSS® 5000 provides the user with the comfort and versatility to meet the demands of first responders whenever breathing protection is required.



- Ergonomic carrying system
- Advanced harness choice
- Service friendly & easy to maintain
- Integrated and Versatile hose routing
- Wide variety of system configurations and accessories
- Electronic Monitoring with the Dräger Bodyguard 7000

Utilizing the established Dräger PSS Pneumatics and cylinder strap design, the Dräger PSS 5000 combines established technology, state-of-the-art materials and innovative thinking to create a SCBA for virtually any application.

#### **ERGONOMIC CARRYING SYSTEM**

The Dräger PSS 5000 has been designed to be not only comfortable but also extremely stable during use in harsh firefighting environments. Incorporating a rigid harness connection to a fixed-height back plate, advanced harness materials and a pivoting waist belt, the Dräger PSS 5000 remains in position regardless of the task in hand.

#### **ADVANCED HARNESS CHOICE**

To allow the breathing apparatus to be tailored to the required application, the Dräger PSS 5000 utilizes new state-

of-the-art harness materials offered in a choice of 2 harness options:

## The Dräger Standard (DS)

Harness is a cost effective option for everyday use, offering a high level of comfort and durability. Easy to don and doff materials and simple pull forward and down adjustment mechanisms make the DS harness a versatile option for a wide variety of applications.

### The Dräger Professional (DP)

Utilizes materials to withstand the high wear and tear that firefighters face daily, whilst providing an enhanced level of comfort and function over the DS harness. Incorporating hardwearing stainless steel buckles and long-life Aramid blend webbing, the DP is ideally suited to extended wear and frequent use.



Dräger PSS® 5000



#### **SERVICE FRIENDLY & EASY TO MAINTAIN**

To keep downtime and costs to a minimum during service and maintenance, the Dräger PSS 5000 incorporates a number of unique design features

- Dräger's innovative Harness "slide and lock" mechanism facilitates fast and simple harness and waist pad connection/removal from the back plate, without the use of tools
- The first stage reducer snap fit connection allows the pneumatics to be fitted or removed quickly and easily from the set
- "Push in and out" hose clips allow swift removal of hoses from the harness pads for cleaning, without the need to remove the clip itself
- Closed, single piece harness and waist pad design to prevent excessive water absorbtion, reducing cleaning and drying time

# INTEGRATED AND VERSATILE HOSE ROUTING

To minimize the risk of snagging and to guard against physical damage, both the gauge and air supply hoses are integrated within channels in the Dräger PSS 5000 back plate. The LDV, Gauge and Rescue hoses can now be routed over the left and/or right shoulders (2 hoses per side), allowing the Dräger PSS 5000 to be configured to any standard. Conventional waist mounted hoses can also be fitted making the Dräger PSS 5000 one of the most versatile SCBA's available.

# WIDE VARIETY OF SYSTEM CONFIGURATIONS AND ACCESSORIES

Dräger has revolutionized the use of breathing apparatus by creating a range of components that can be selected in combination to meet the specific needs of the firefighter regardless of the task.

In addition to the inherent features of the Dräger PSS 5000 DS and DP, it is also possible to add

- Dräger Bodyguard 7000 electronic monitoring
- twin cylinder configuration
- Quick-Connect (QC) cylinder connection
- chargeair quick filling
- secondary supply connections for rescue, decontamination and/or airline use
- PSS Merlin Modem
- PSS Rescue Hood
- and many more ... (for a full list and information please refer to the Dräger CABE Family Catalogue)

# ELECTRONIC MONITORING WITH THE DRÄGER BODYGUARD 7000

The Dräger PSS 5000 has been designed to be fully compatible with the globally established Dräger Bodyguard 7000 electronic signal and warning unit, and the newly integrated PSS Merlin Modem.

For maximum protection the Dräger Bodyguard 7000 has an innovative compact design that integrates the power supply and pressure sensor modules within the back plate, creating a balanced weight distribution. Real-time monitoring of essential information such as

time-to-whistle (based on current air consumption) and cylinder pressure is communicated via a lightweight handheld electronic gauge and display and/or, a facemask-mounted Head's Up Display (HUD).

Simultaneously this information can be transferred to an Entry Control Board via the PSS Merlin Modem, further enhancing firefighter and fire ground safety.

## DRÄGER BODYGUARD 7000 AT A GLANCE

- accurate, continuously updated air time remaining
- digital and Analogue display of cylinder pressure
- time to whistle (based on current air consumption)
- intuitive operation
- integrated personal alert safety system (PASS)
- visual and acoustic warnings and alarms (102 to 112 dBA)
- easy push-button operation
- configurable settings to suit individual preferences
- enhanced display with scrolling text
- automatic self tests and system tests
- datalog with personal ID
- PC Link Software (Windows® compatible)
- choice of operating modes:Tally and Automatic
- simple upgrade to Dräger FPS® 7000
   Head-Up- Display (HUD)
- simple integration with the Dräger PSS Merlin Modem

## DRÄGER PSS 5000



## Dräger PSS® 5000 Rescue Hose Shoulder



Left Hand Shoulder 3358341

Right Hand Shoulder 3358340





High-Tech Harness
Closed, single piece harness and waist pad
design to prevent excessive water absorbtion,
reducing cleaning and drying time.

### TECHNICAL INFORMATION

	PSS® 5000 DS Pneumatic Gauge	PSS <sup>®</sup> 5000 DP Pneumatic Gauge	PSS <sup>®</sup> 5000 DP Bodyguard 7000
Weight Kg (Backplate and Harness)	3.85	4.00	4.60
Input Pressure (bar)	0 - 300	0 - 300	0 - 300
Nominal 1st Stage output pressure	7.5	7.5	7.5
1st stage output flow (I/min)	> 1,000	> 1,000	> 1,000
LDV output flow (I/min)	> 400	> 400	> 400
Whistle activation pressure (bar)	50 - 60	50 - 60	50 - 60
Whistle Sound Level (dBA)	> 90	> 90	> 90
ADSU Main alarm (dBA)	N/A	N/A	102 – 112

Approvals EN 137:2006 (Type 2)

### SELECTED ACCESSORIES/UPGRADES



Dräger Bodyguard 7000



Dräger FPS® 7000



Dräger FPS® 7000 Head-Up Display



Dräger PSS® Rescue hood



Plus LDV



Cylinder Quick Connect



Dräger PSS® Merlin Modem



Dräger PSS® 7000 secondary supply hose



Dräger Bodyguard 1000



AA battery module



Desktop charger (shown with batteries)



Nickel Metal Hydride battery module

## ORDER INFORMATION

Dräger PSS® 5000 Compressed Air Breathing Apparatus		00.57.045
PSS® 5000 DP Pneumatic Gauge	single cylinder strap	33 57 845
PSS® 5000 DP Pneumatic Gauge PSS® 5000 DP Quick Connect	universal cylinder strap	33 58 333
	single cylinder strap single cylinder strap	33 58 431 33 58 353
PSS® 5000 DP Bodyguard 7000 PSSv 5000 DP Bodyguard 7000	universal cylinder strap	33 58 355
PSS® 5000 DP Bodyguard 7000 QC	single cylinder strap	33 58 436
PSS® 5000 DP Bodyguard 7000 QC	single cylinder strap	33 58 354
PSS® 5000 DP Bodyguard 7000 Tally	universal cylinder strap	33 58 356
PSS® 5000 DP Bodyguard 7000 Tally Quick Connect	single cylinder strap	33 58 437
PSS® 5000 DS	single cylinder strap	33 57 858
PSS® 5000 DS	universal cylinder strap	33 58 338
PSS® 5000 DS Quick Connect	single cylinder strap	33 58 428
PSS® 5000 DS Bodyguard 7000	single cylinder strap	33 58 349
PSS® 5000 DS Bodyguard 7000	universal cylinder strap	33 58 351
PSS® 5000 DS Bodyguard 7000 Quick Connect	single cylinder strap	33 58 434
PSS® 5000 DS Bodyguard 7000 Tally	single cylinder strap	33 58 350
PSS® 5000 DS Bodyguard 7000 Tally	universal cylinder strap	33 58 352
PSS® 5000 DS Bodyguard 7000 Tally Quick Connect	single cylinder strap	33 58 435
Selected Accessories FPS 7000 HUD Transmitter Kit 1		33 56 882
consisting of pressure module and HP manifold (allows upg gauge to FPS 7000 Heads-Up-Display) n-mask display and	,	
Bodyguard 7000 Upgrade Kit (Tally)		33 57 098
consisting of Bodyguard 7000 display module & pressure N	·	
(Upgrade of PSS® 5000 with pneumatic gauge to PSS® 50	00 w Bodyguard 7000, power supply not included)	
Bodyguard 7000 Upgrade Kit (Button)	33 57 101	
PSS® Merlin Modem Kit		33 57 982
Plus lung demand valve (LDV)		
Normal Demand (N)	33 50 501	
Plug in (A)	33 38 700	
M45 (AE)	33 38 706	
ESA	33 51 302	
Automatic switch over valve (ASV)	on request	
PSS Rescue hood	33 54 982	
Lung demand valve holder		
N/ESA		33 57 526
AE	33 57 528	
A	33 57 527	
Dräger Cylinders	on request	
Secondary Supply & Airline Accessories		
2nd MP Connector Hose – Waist – Female – LF	33 55 748	
2nd MP Connector Hose – Waist – Male – LF	33 55 749	
2nd MP Connector Hose - Waist - Female - SF	33 58 503	
2nd MP Connector Hose - Shoulder RH - Female - QRC	33 58 340	
2nd MP Combined Connector Hose - Weight Upgerund	33 58 341	
2nd MP Combined Connector Hose – Waist – Unsecured 2nd MP Combined Connector Hose Forward – Waist – Se	33 56 530	
2nd MP Combined Connector Hose Forward – Waist – Se 2nd MP Combined Connector Hose Forward – Waist – Se	33 58 403	
Zina ini. Combinea Connector Flose Forwara – Walst – Ge	cured	33 58 406
Buddy Breather Pouch	cured	33 58 406 33 58 596
Buddy Breather Pouch Revitox Shoulder Hose	cured	33 58 406 33 58 596 33 58 590

## CORPORATE HEADQUARTERS

Drägerwerk AG & Co. KGaA Moislinger Allee 53–55 23558 Lübeck, Germany

www.draeger.com

#### Manufacturer:

Dräger Safety AG & Co. KGaA Revalstraße 1 23560 Lübeck, Germany

#### AUSTRALIA

Draeger Safety Pacific Pty. Ltd. 8 Acacia Place Notting Hill VIC 3168 Toll-free +61 1800 DRAGER (1800 372 437) Fax +61 1800 64 74 84 customer.service@draeger.com

#### CANADA

Draeger Safety Canada Ltd. 2425 Skymark Avenue, Unit 1 Mississauga, Ontario, L4W 4Y6 Tel +1 905 212 6600 Toll-free +1 877 Drager 1 (+1 877 372 4371) Fax +1 877 651 0902 Toll-free Fax +1 800 329 8823

#### P. R. CHINA

Draeger Safety Equipment (China) Co., Ltd. A22 Yu An Rd, B Area, Tianzhu Airport Industrial Zone, Shunyi District, Beijing 101300 Tel +86 10 80 49 80 00 Fax +86 10 80 49 80 05

#### FRANCE

Dräger Safety France SAS Tel +65 68 72 92 88 3c route de la Fédération, BP 80141 Fax +65 65 12 19 08 67025 Strasbourg Cedex 1 Tel +33 3 88 40 76 76 Fax +33 3 88 40 76 67

#### MEXICO

Draeger Safety S.A. de C.V.
Av. Peñuelas No. 5 Bodega No. 37
Fraccionamiento Industrial
San Pedrito
Querétaro, Qro México
Tel +52 442 246-1113
Fax +52 442 246-1114

#### NETHERLANDS

Dräger Safety Nederland B.V. Edisonstraat 53 2700 AH Zoetermeer Tel +31 79 344 46 66 Fax +31 79 344 47 90

### REGION ASIA PACIFIC

Draeger Safety Asia Pte Ltd. 67 Ayer Rajah Crescent #06-03 Singapore 139950 Tel +65 68 72 92 88 Fax +65 65 12 19 08

## REGION CENTRAL

#### AND SOUTH AMERICA

Dräger Panama Comercial S. de R.L. Complejo Business Park, V tower, 10th floor Panama City Tel +507 377-9100 Fax +507 377-9130 contactcsa@draeger.com

## REGION MIDDLE EAST, AFRICA

Dräger Safety AG & Co. KGaA Branch Office P.O. Box 505108 Dubai, United Arab Emirates Tel +971 4 4294 600 Fax +971 4 4294 699 contactuae@draeger.com

#### SPAIN

Dräger Safety Hispania S.A. Calle Xaudaró 5 28034 Madrid Tel +34 91 728 34 00 Fax +34 91 729 48 99

## UNITED KINGDOM

UNITED KINGDOM
Draeger Safety UK Ltd.
Blyth Riverside
Business Park
Blyth, Northumberland
NE24 4RG
Tel +44 1670 352-891
Fax +44 1670 356-266

#### USA

Draeger Safety, Inc. 101 Technology Drive Pittsburgh, PA 15275 Tel +1 412 787 8383 Fax +1 412 787 2207