

POSEIDON EDITION

COMPRESSORS FOR SPORTS & SAFETY APPLICATIONS



SPORTS & SAFETY




USER-FOCUSED FEATURES, UNCOMPROMISING QUALITY

FOR MORE INFORMATION

about our product programme and the products shown here, visit our website at www.bauer-kompressoren.de

CONTENTS

COMPANY	5
APPLICATIONS	6
PERFORMANCE OVERVIEW	8
 FEATURES AND HIGHLIGHTS Compressor Block Air and Breathing Air Purification Systems Drive Systems and Motors Automation and Compressor Control 	9 10 12
MOBILE COMPRESSORS 1	16
STATIONARY COMPRESSORS	21 23
ACCESSORIES 2	27
SERVICES	30
ACCEPTANCE AND SERVICES	31



COMPANY

BAUER – PASSIONATE ABOUT THE PERFECT SOLUTION

BAUER stands for a long tradition of mechanical engineering. As early as 1888, Johann Bauer, a blacksmith in the Bavarian village of Arnstorf, founded an agricultural machinery factory. In 1946, his son Hans Bauer launched a post-war German success story. Bauer started by developing low-pressure compressors, quickly recognising the potential for novel high-pressure compression technology. Accordingly, in the 1960s BAUER KOMPRESSOREN rose to become the global leader in the manufacture of breathing air compressors, especially in the area of scuba diving and fire fighting.

Then as now, the cornerstone of our company's success and the springboard for our global expansion are our passion for developing the best solution, in terms of both technology and costs, and our high quality standards. Today, BAUER KOMPRESSOREN operates a global network of companies and is represented by its subsidiaries in many high-growth markets where German quality is especially appreciated.

BAUER KOMPRESSOREN supplies one-stop state-of-the-art solutions tailored to your needs in the Sports & Safety sector – from compression and purification to air, breathing air and nitrox distribution.

Pure breathing air is an essential part of equipment. Compressed and purified in our top-level systems, it protects the lives, health and property of our customers in all situations. All our employees are driven by their passion for providing 100% safety and security for people all over the world – our motivation for performance and success.

We certify pure breathing air to EN 12021:2014 standards. In addition, our BAUER PureAir Certification provides divers in particular with guidance in selecting a trustworthy filling station for pure breathing air.

Place your trust in BAUER KOMPRESSOREN and the outstanding quality and safety of the global market leader for breathing air systems.

APPLICATIONS

DIVING

Breathing air is the most important part of diving equipment – in both scuba diving and professional diving.

A safe supply of pure breathing air for the diver is therefore the top priority for BAUER KOMPRESSOREN. This applies to systems from portable breathing air compressors for private use to professional system installation in diving centres.





In the event of an emergency, whether at the heart of a fire or in contaminated environments, fire fighters must be able to rely on everything – their team members, their protective equipment and, above all, an absolutely reliable supply of breathing air. BAUER KOMPRESSOREN offers tailored unit concepts. Whether the unit is located at the fire station for rapid, reliable deployment or is on site as a mobile unit in the rescue vehicle, our systems provide assurance. 24 hours a day – 365 days a year.

SHIPPING

Once on the high seas, ships become self-sufficient systems. Every technical device on board has to function completely reliably. Thanks to their excellent quality, systems and accessories from BAUER KOMPRESSOREN easily outperform the specified technical requirements regarding safety and reliability and are confirmed and certified by reputable independent inspection companies including Germanischer Lloyd and DNV.





Many things we are accustomed to in our daily lives, such as navigation systems, diving equipment and tracked vehicles, were originally developed for military purposes. Whether land, sea or air applications, the products used must be absolutely reliable and safe. BAUER KOMPRESSOREN supplies individual solutions tailored to customers' needs.









MEDICAL ENGINEERING

For treatment purposes patients are exposed to increased atmospheric pressure in pressure chambers, such as for divers following decompression accidents in order to protect them from the consequences of the 'bends'. Every minute counts – as does a totally reliable provision of pure, oxygen-enriched breathing air. Hospitals use pressure chambers for hyperbaric oxygen therapy (HBOT). BAUER KOMPRESSOREN supplies the breathing air required.



PAINTBALL/SHOOTING SPORTS

Today, air guns used by sports marksmen and markers of paintball teams are powered by air from high-pressure cylinders. The precision mechanisms of this sports equipment require pure and dry compressed air, which is provided by compressors from BAUER. Our special user-friendly filling devices feed the required precisely measured quantity of air into the cartridges quickly and safely.



MOTOR SPORTS

Whether DTM or Formula 1, motor racing is a highly competitive sport where fractions of a second make all the difference —particularly in the pits, where the interplay between driver and service team can clinch victory or defeat. Throughout this fascination with speed, reliable interaction of all the high-quality elements involved is essential. Our compressor systems assure complete, reliable and precise air logistics; car jacks and tools are operated by compressed air; and our tailored storage solutions ensure that even in case of demand peaks, the required air quantity is always available.

PERFORMANCE OVERVIEW

OUTSTANDING COMPRESSOR SOLUTIONS TO MEET ALL YOUR NEEDS

BAUER KOMPRESSOREN filling systems ensure optimum availability and safety in reliable supply of pure breathing or compressed air for all applications, in compliance with international air quality standards such as DIN EN 12021:2014 (Breathing Air Standard).

BAUER KOMPRESSOREN produces high-pressure compressors for air, breathing air and nitrox compression, using state-of-the-art technology in outstanding quality. With decades of experience, we have gathered extensive expertise in the fields of development, production and application.


In the Sports & Safety sector, we develop and manufacture mobile compressors and compressors for stationary use, optionally supplied with sound-insulating housing. Select the high-pressure compressor with the right drive system, maximum operating pressure and required output for your needs from our extensive product range.

BAUER POSEIDON EDITION breathing air compressors provide an outstanding price/performance ratio and excellent quality.


The POSEIDON EDITION series was designed for straightforward, easy operation and combines proven BAUER core components with rugged, simple housing.

They naturally feature BAUER's hallmark durability, high safety levels and pure breathing air quality in compliance with international standards.

MOBILE COMPRESSORS | 225 - 330 BAR



STATIONARY COMPRESSORS | 225 - 330 - 420 BAR



COMPRESSOR BLOCK

Each and every one of our compressor blocks contains decades of experience and the expertise of our Testing and Development Centre. BAUER compressor blocks have built a legendary reputation on their reliability and long service life. They are the result of advanced design, intelligent in-depth solutions, the use of exceptionally high-quality materials and outstanding production quality.

PE 100 COMPRESSOR BLOCK

- > Minimised operating costs: long oil change intervals, wear-resistant piston rings and optimised cooling system significantly reduce running costs.
- Oil changes are made simple by the easily accessible oil filler neck. A dipstick is supplied for easy, reliable oil level checks.
- > Benefit from our years of experience: over 100,000 compressor blocks sold in this supply volume range.

COMPRESSOR BLOCKS FOR TE-HE, PE-HE, PE-MVE AND PE-VE SERIES

- > With industrial roller bearings, proven thousands of times over.
- > Extra-long operating life: cylinders are plasma-nitrided and plateau-honed for outstanding surface hardness. The final-stage cooler has stainless-steel ribs for maximum cooling efficiency.
- Low operating costs: wear-resistant piston rings in the final stage keep the running costs of the unit low. As a further advantage, a highly reliable oil lubrication system for the cylinder faces ensures low energy consumption and maximises service life.



PE 100 Compressor Block



IK 120 Compressor Block (used in PE-TE, -HE, -MVE and -VE)

AIR AND BREATHING AIR PURIFICATION SYSTEMS

Whether you rely on pure breathing air to DIN EN 12021:2014 standards as a diver or fire fighter or seek optimised pure compressed air for sports applications such as filling paintball cylinders, BAUER offers over 65 years of experience in air purification, in-depth research and tough material testing, adding up to outstanding quality and maximum safety.

In highly compressed air and gas purification, our aim is to minimise contamination from moisture, CO, CO₂, oil and particulates. As the market leader, BAUER KOMPRESSOREN supplies air purification systems that have built an excellent reputation worldwide for their cost-effectiveness and quality.

We supply a range of purification systems for many different applications: filter cartridge systems, regeneration and refrigeration dryers and an array of monitoring devices for ensuring compliance with specific air quality threshold values.

BAUER KOMPRESSOREN IS CERTIFIED FOR THE MANUFACTURE OF CATEGORY 4 PRESSURE EQUIPMENT UNDER THE EU PRESSURE EQUIPMENT DIRECTIVE PED97/23/EC.

P-PURIFICATION SYSTEMS (FILTER CARTRIDGE SYSTEMS)

This range is the undisputed classic among BAUER's purification systems. Its major benefits include rapid and straightforward cartridge change, minimum downtime and cost-effective operation.

BAUER P-Purification Systems reliably remove hazardous substances and deliver pure breathing air for your use. A P-Purification System is supplied as standard with every BAUER Sports and Safety compressor.

Depending on the filter type, P-Purification Systems adsorb residual moisture, oil vapour, traces of hydrocarbon cases and carbon monoxide from the compressed air. BAUER P-Purification Systems not only meet, but actually exceed all requirements of the DIN EN 12021:2014 Breathing Air Standard¹.

DIN EN 12021:2014-07	7 Breathing Air Standard ² :
	Threshold values
Oxygen (O ₂)	21 % ± 1 %
Carbon monoxide (CO)	5 ppm
Carbon dioxide (CO_2)	500 ppm
Oil	0.5 mg/m ³
H ₂ O	25 mg/m ³

¹ Based on due maintenance and installation of the system in accordance with the operating manual and only where CO₂ concentrations in intake air do not exceed the predefined standard values. Local TLVs are not considered.

² The table shows the limits for breathing air in the definition of the DIN EN 12021:2014-07 Breathing Air Standard.

In addition to the P-Purification Systems, we supply the following air purification and monitoring systems:

PURIFICATION

- > B-KOOL Refrigeration dryer that can extend filter cartridge life for ultra-cost-effective operation.
- > AERO-GUARD Reduces CO, content of intake air.
- > SECCANT Regeneration dryer the safe, low-maintenance way to dry air, boosting charging rates and extending operating life.

In addition to the integrated P-Purification Systems supplied as standard, you have the option of selecting a larger filter system for PE-TE, PE-HE and PE-MVE Series systems to allow longer cartridge life.



P 31 Purification System

MONITORING

- > B-TIMER Calculates filter lifetime and displays filter cartridge change warning, maintenance requirements and operating hours.
- B-SECURUS Monitors filter cartridge saturation while reliably measuring moisture in the cartridge to calculate remaining cartridge life.
- B-DETECTION Online gas measurement systems for continuous monitoring of compliance with DIN EN 12021:2014 Breathing Air Standard¹.
- > PureAir and PureAir Gold Certification BAUER's seal of quality for your pure breathing air.



B-SECURUS: Measures cartridge saturation and displays remaining cartridge life using a traffic light system.

For more information on air and gas purification by BAUER, see our brochure "BAUER Accessories" and visit www.bauer-kompressoren.de

DRIVE SYSTEMS AND MOTORS

V-BELT DRIVE

The low-maintenance V-belt drive enables the compressor block speed to be optimised regardless of the network frequency and motor type.

The compressors are in vertical or horizontal format depending on the model series. The stationary systems in the POSEIDON EDITION feature automatic adjustment of the V-belt tension.

Tension is ensured by the weight of the motor in vertical format (PE-MVE and PE-VE), and by use of a belt tensioning device (PE-HE) in horizontal format.

MOTORS

Our PE 100 mobile system is also available with three-phase AC motor, single-phase AC motor or petrol engine for operation at any locations.



PE-HE: V-belt adjustment is likewise unnecessary in this horizontal model by use of a belt tensioning device.

Interior view of PE-VE: Adjustment of the V-belt is not necessary because of the vertical format and suspended motor mounting.

AUTOMATION AND COMPRESSOR CONTROL

AUTOMATION

All separators in the compressor must be continuously drained during compressor operation to remove the aggressive oil/water mixture (condensate) produced by the compression process.

POSEIDON EDITION mobile compressors are supplied with a manual condensate drain system as standard. An automatic condensate drain system and electronic control unit can be integrated into compressors from the PE-TE series upwards. The compressor then operates in semi-automatic mode, i.e. no operator intervention is necessary during filling and the compressor automatically shuts down when the system reaches final pressure.

This mode saves the operator significant time, effort and costs. The control unit also displays operating hours and has a warning light for incorrect rotation direction.

Compressor control units for the PE-TE Series (optional) and PE-HE Series as well as PE-MVE Series (integrated as standard) are optimised for straightforward and user-friendly operation.



Easy-to-operate control unit for PE-HE and PE-MVE with phase monitoring, main switch, operating hours counter and on/off switch.



Save time with automatic compressor operation: automatic condensate drain system fitted to a PE-TE.


B-TIMER

The patented mini-computer B-TIMER can also be used with mobile systems without a control unit¹. B-TIMER shows operating hours and the filter cartridge saturation level, has a flashing light to warn of approaching cartridge changes and displays the order number of the required filter cartridge, ensuring that filter cartridge life is maximised.



B-TIMER: Calculates and displays remaining filter cartridge lifetime and any maintenance required.

B-CONTROL MICRO



B-CONTROL MICRO

B-CONTROL MICRO is a modern, easy-to-use compressor control unit with colour display that provides intelligent control and safe monitoring of all basic functions. The unit is integrated into all PE-VE Series systems as standard and enables compressor systems to be operated fully automatically¹. It is therefore also optimum for operation with storage solutions.

Interaction between user and control unit is user-friendly and logical. An extensive language selection is now available².

As a further benefit, interfacing with external input/output signal encors is possible at any time, as is interconnected operation or the connection of an external display unit.

- > 3.5" TFT colour display with clear text
- > Fully automatic monitoring of relevant parameters; compressor shutdown if values are outside permissible ranges
- > Oil pressure monitoring protects against incorrect rotation direction
- > Software is simple to update using an SD card
- > Unique: display of remaining time to fill your pressurised air cylinder
- > Improved filter monitoring: if a B-SECURUS filter monitoring system is installed in your compressor system, the start display already shows predicted results such as current cartridge saturation level and cartridge change date



PE 100 AND PE-TE SERIES

Our mobile POSEIDON EDITION compressors combine proven core components with user-optimised features.

The PE 100 is by far the most compact and lowest-weight system in the PE Series. Available in three drive types (petrol engine, three-phase motor or single-phase AC motor), it is ideal for a wide range of applications on land or sea and in vehicles.

Compact in design yet delivering charging rates of up to 300 I/min, PE-TE Series compressors are easy to transport and load into vehicles. The oil pump allows the compressors to be operated at inclinations of up to 15 degrees, so that this series is also suitable for shipping applications.

PE 100

RUGGED TECHNOLOGY - COMPACT FOOTPRINT

Ruggedness, reliability, a wide range of applications and compact portability are all features of the PE 100.

Its range of applications is virtually unlimited. Available in three drive types with petrol engine, three-phase or single-phase AC motor, it is ideal for many uses, such as a breathing air compressor for diving groups or fire fighters or for rapid filling of cartridges for sports shooting or paintball cylinders.

The PE 100-TW sports shooting version has a non-bleed filling valve including adapter for filling cartridges and was designed specifically for sports shooting applications.

In the version with petrol engine, the PE 100 can be operated without an external power source in even the most remote locations. In the single-phase AC motor version, it can be powered from a household power supply.

- > 100 l/min
- > 225 or 330 bar
- > 2.2 kW (4.2 kW petrol version)
- > Available with three-phase motor, single-phase AC motor or petrol engine

FEATURES

- Compact, low-weight system, easily transportable
- The P 11 purification system designed especially for the PE 100 supplies pure breathing air in compliance with DIN EN 12021:2014¹
- > Many possible applications



PE 100, 300 bar model

FOR ANYONE THAT WANTS TO RELY ON PURE, SAFE BREATHING AIR IN MOBILE APPLICATIONS.

OPTIONAL FEATURES

Motor protection switch for PE 100-TE

TECHNICAL DATA

Туре	Charging Rate ¹				Purification System	Number of Stages	Speed	Drive and Motor Power		Net Weight approx.	Dimensions L x W x H
	l/min	cfm	bar	psig			rpm	Motor	kW	kg	cm
PE 100-TB	100	3.5	330	4780	P 11	3	2,300	Petrol engine 4-stroke	4.2	42	78 x 34 x 42
PE 100-TE	100	3.5	330	4780	P 11	3	2,300	Three-phase 400 V, 50 Hz	2.2	44	66 x 35 x 42
PE 100-TW	100	3.5	330	4780	P 11	3	2,300	Single-phase 230 V, 50 Hz ^{3,4}	2.2	44	66 x 35 x 42
PE 100-TW ² Sports Shoo- ting Version	100	3.5	330	4780	P 11	3	2,300	Single-phase 230 V, 50 Hz ²	2.2	44	66 x 35 x 42

1 Measured by tank filling (10 l) from 0 - 200 bar / 2900 psig, \pm 5%.

2 Filling valve without automatic vent including adapter for connecting adapters cartridges.

3 Plug dimension: Schuko plug. Plug only for units with 230 V / 50 Hz.

4 With integrated motor protection switch (only for 220/230/240 V).





MOBILE COMPRESSOR SYSTEMS WITH OPTIMISED FEATURES FOR USE IN VEHICLES AND SHIPPING

The PE-TE Series was developed for high charging rates of up to 300 I/min and is thus ideal for private or commercial operation of filling stations. With compact design and functional carry frame, these compressors are easy to transport and stow in vehicles.

Their integrated oil pump enables them to be operated at inclinations of up to 15 degrees, so that this series is particularly suitable for shipping applications.

Also included is the BAUER P 21 Purification System (optionally available: P 31 or P 42). This sophisticated air purification system with integrated oil and water separator and pressuriser valve reliably prevents users from inhaling air impurities¹ and provides effective protection from icing up when cartridges are changed regularly.

> 200 - 300 l/min

> 225 or 330 bar

) 4 – 7.5 kW

FEATURES

- High charging rate, yet low in weight and easy to transport
- Ideal for marine use, with interstage and afterstage cooler in stainless steel. Highly corrosion-resistant
- Optionally available with user-friendly ultra-rugged B-TIMER mini-computer for filter cartridge monitoring



PE 250-TE with optional control unit

OPTIONAL FEATURES

- > Additional filling device for 225 or 330 bar
- > Switchover device for 225/330 bar (not available for P 31)
- Larger Purification System P 31 (for PE 250 and PE 300-TE only) or P 41 Purification System (for PE 300-TE only) for longer cartridge life
- > B-TIMER filter cartridge lifetime monitoring system
- > B-SECURUS filter cartridge saturation monitoring system (for P 42 only)
- > Electronic control unit
- > Automatic condensate drain including automatic shut off when final pressure is reached

1 Based on due maintenance and installation of the system in accordance with the operating manual and only where CO₂ concentrations in intake air do not exceed the predefined standard values. Local TLVs are not considered.

TECHNICAL DATA

Туре	Charging Rate ¹				Operating Pressure max.		Purification System	Number of Stages	Speed	Drive and Motor Power		Net Weight approx.	Dimensions L x W x H
	l/min	cfm	bar	psig	_	_	rpm	Motor	kW	kg	cm		
PE 200-TE	200	7	330	4780	P 21	3	1,250	Three-phase 400 V, 50 Hz²	40	120	110 x 50 x 57		
PE 250-TE	250	9	330	4780	P 21	3	1,450	Three-phase 400 V, 50 Hz²	5.5	130	110 x 50 x 57		
PE 300-TE	300	10	330	4780	P 21	3	1,800	Three-phase 400 V, 50 Hz²	7.5	140	110 x 50 x 57		

1 Measured by cylinder filling (10 l) from 0 - 200 bar, \pm 5%.

2 Plug dimension: Schuko plug 16 A.



STATIONARY COMPRESSORS



PE-HE, PE-MVE AND PE-VE SERIES

POSEIDON EDITION stationary compressors are designed specifically for individual needs and performance requirements in the breathing air sector.

They are supplied with an integrated purification system and intuitive controls, reflecting our priority to optimise ease of operation. The PE-HE, PE-MVE and PE-VE Series have features optimised for users' needs, with BAUER's hallmark quality and reliability for the utmost safety in stationary operation.

PE-HE

AMONG THE MOST COMPACT STATIONARY COMPRESSOR SYSTEMS IN ITS PERFORMANCE CLASS

The POSEIDON EDITION PE 250-HE and PE 300-HE horizontal compressors from BAUER KOMPRESSOREN are among the most compact stationary systems in their class.

The integrated P 31 Purification System provides reliable breathing air purification in compliance with DIN EN 12021:2014¹.

Thanks to the space-saving arrangement of compressor block and drive, the rugged and durable units in the HE series take up next to no floor space.

They are also supplied with an automatic condensate drain system and the user-friendly BHW-CONTROL control unit as standard.

> 250 - 300 l/min

- > 225 or 330 bar
-) 5.5 7.5 kW

FEATURES

- > With rugged compressor block and piston rings of wear-proof special plastic
- > Easy-to-use compressor control
- > Small footprint, in compact horizontal design

OPTIONAL FEATURES

- > 2-way filling device with hose coupling / 4-way filling device with hose coupling or direct coupling
- > Two pressure ranges 225 and 330 bar (pressure reducer)
- Large-scale P 42 Purification System for longer cartridge life
- > B-TIMER filter cartridge lifetime monitoring system
- > B-SECURUS filter cartridge saturation monitoring system
- > AERO-GUARD CO₂ reduction system
- > External BAUER filling panels
- > BAUER high pressure storage system



PE 300-HE with two filling hoses (optional)

TECHNICAL DATA

Туре	Charging Rate ¹				Operating Pressure max.		Purification System	Number of Stages	Speed	Drive and Motor Power		Net Weight approx.	Dimensions L x W x H
	l/min	cfm	bar	psig			rpm	Motor	kW	kg	cm		
PE 250-HE	250	9	330	4780	P 31	3	1,450	Three-phase 400 V, 50 Hz ²	5.5	220	110 x 69 x 99		
PE 300-HE	300	10	330	4780	P 31	3	1,800	Three-phase 400 V, 50 Hz²	7.5	230	110 x 69 x 99		

1 Measured by cylinder filling (10 l) from 0 - 200 bar, \pm 5%

2 Plug dimension: 16 A



PE-MVE

SPACE-SAVING ALL-IN-ONE SOLUTION AT ATTRACTIVE PRICE FOR EXTRA-LOW-NOISE OPERATION

The PE-MVE is BAUER's compact all-in-one solution, offering high quality at outstanding value for money. The unit is in vertical format and ideal for all applications requiring medium charging rates. Supplied as standard with Super Silent housing, the unit provides for a variety of installation options even in noise-sensitive environments. The soundproof PE-MVE is ideally suited for applications that prioritise reliability and long operating life combined with low operating costs.

It is also supplied with an automatic condensate drain system and the user-friendly BHW-CONTROL control unit as standard; the fully automatic BHW-CONTROL also supports storage cylinder filling.

FEATURES

- Silent housing as standard: With low noise level for use in working environments where noise is a key concern
- > Easy-to-use compressor control, optional fully automatic
- Integrated filling device: Supplied with 2 kinkproof filling hoses as standard
- > Ultra-compact dimensions for installation where space is at a premium
- > 250 300 l/min
- > 225 or 330 bar
- > 5.5 7.5 kW

OPTIONAL FEATURES

- Large-scale P 42 Purification System for longer cartridge life
- B-TIMER filter catridge lifetime monitoring system in combination with P 31
- B-SECURUS filter cartridge saturation monitoring system in combination with P 42
- > BAUER high pressure storage system
- > Automatic selector unit




TECHNICAL DATA

Туре	Charging Rate 1		Operating Pressure max.		Purification System	Number of Stages	Speed	Drive and Motor Power		Net Weight approx.	Dimensions L x W x H
	l/min	cfm	bar	psig			rpm	Motor	kW	kg	cm
PE 250-MVE	250	9	350	5000	P 31	3	1,470	400 V, 50 Hz²	5.5	250	104 x 75,5 x 132
PE 300-MVE	300	10	350	5000	P 31	3	1,800	400 V, 50 Hz²	7.5	260	104 x 75,5 x 132

1 Measured by cylinder filling (10 l) from 0 - 200 bar, \pm 5%

2 Plug dimension: 16 A





PE-VE

PE-VE SERIES – FOR UNIVERSAL USE WITH CHARGING RATES UP TO 850 L/MIN

The PE-VE Series offers impressive peak free air delivery rates of up to 850 l/min.

Professionally customised to meet individual needs and charging rate requirements in breathing air applications, PE-VE units feature practical functions, BAUER's hallmark quality and certified safety for reliable stationary operation

The compressors are available in versions for 225 bar and/or 330 bar and for 420 bar.

The modular design of the PE-VE Series enables the units to be ideally aligned to your needs.

The B-CONTROL MICRO demand-driven electronic control unit features clear functional menu-based operation for safe, secure and convenient use and enables the compressor to be controlled fully automatically.

- > 300 850 l/min
- > 225/330/420 bar
-) 7.5 18.5 kW

FEATURES

- > Optional Super Silent housing to minimise noise
- Demand-driven electronic compressor control unit: B-CONTROL MICRO
- > Low-maintenance: no V-belt adjustment necessary

OPTIONAL FEATURES (SELECTED)

- > Super Silent soundproof housing
- > B-SECURUS filter cartridge saturation monitoring system
- > Filling device for 4 x 200 bar / 4 x 300 bar¹
- > B-KOOL refrigeration dryer¹
- > AERO-GUARD CO2 reduction system
- > BAUER high pressure storage system
- > Automatic selector unit
- > External BAUER filling panel



PE 850-VE with B-CONTROL MICRO control unit and optional Super Silent housing

TECHNICAL DATA

PE-VE UP TO 350 BAR

Туре	Charging Rate ¹								Purification System	on Number of Stages Speed		Drive and Motor Power		Net Weight approx. ²	Dimensions ³ L x W x H
	l/min	cfm	bar	psig			rpm	Motor	kW	kg	cm				
PE 300-VE	300	11	350	5000	P 42	3	1,800	400 V/50 Hz 4	7.5	299	114 x 83 x 152				
PE 400-VE	400	14	350	5000	P 42	4	1,800	400 V/50 Hz ⁴	11	304	114 x 83 x 152				
PE 550-VE	550	20	350	5000	P 42	4	1,230	400 V/50 Hz 4	11	378	114 x 83 x 152				
PE 700-VE	700	25	350	5000	P 61/350	4	1,400	400 V/50 Hz ⁵	15	403	114 x 83 x 152				
PE 850-VE	850	30	350	5000	P 61/350	4	1,800	400 V/50 Hz ⁵	18.5	425	114 x 83 x 152				

1 Measured by cylinder filling (10 I) from 0 - 200 bar, \pm 5%

2 Weight of Super Silent version approx. 90 kg higher

3 Dimensions of Super Silent version: 148 x 83 x 152 cm / 160 x 83 x 152cm (PE 850)

4 Plug dimension: 32 A

5 Without plug

PE-VE UP TO 420 BAR

Туре	Charging Rate ¹						Operating Pressure max.		Purification System	Number of Stages	Speed	Drive and Motor Power		Net Weight approx. ²	Dimensions ³ L x W x H
	l/min	cfm	bar	psig			rpm	Motor	kW	kg	cm				
PE 320-VE	320	11.5	420	6000	P 41/420	4	1,450	400 V/50 Hz ⁴	7.5	299	114 x 83 x 152				
PE 500-VE	500	18	420	6000	P 41/420	5	1,170	400 V/50 Hz ⁴	11	304	114 x 83 x 152				
PE 600-VE	560	19.8	420	6000	P 61/420	5	1,490	400 V/50 Hz ⁴	11	378	114 x 83 x 152				

1 Measured by cylinder filling (10 l) from 0 - 200 bar, \pm 5%

2 Weight of Super Silent version approx. 90 kg more

3 Dimensions of Super Silent version: 148 x 83 x 152 cm

4 Plug dimension: 32 A



BAUER KOMPRESSOREN supplies an extensive range of accessories for its compressor systems.

From air purification to control, storage, gas measurement and distribution – intelligent BAUER accessories enable you to align your system precisely to your needs, enhancing its cost-effectiveness and economical operation or expanding its range of applications.





External cartridge purification system



- > AERO-GUARD CO₂ Adsorber reduces CO₂ in intake air
- > External cartridge purification systems
- > B-KOOL Refrigeration Dryer extends cartridge life
- SECCANT Regeneration Dryer extends cartridge life and maximises operating hours and charging rates



AERO-GUARD





STORAGE AND DISTRIBUTION

B-KOOL

- > Single high-pressure cylinders
- > Storage cylinder racks with one or more storage cylinders
- > Optional safety valve for maximum safety
- > Automatic selector unit for fast, economical filling of storage cylinders



Automatic selector unit

FILLING AND SAFETY

- > External filling panels for wall mounting, with optional remote control unit
- > B-SAFE Safety Filling System for safe filling of breathing air cylinders
- FSC Filling Speed Control unit reduces filling speed to 20 up to 50 bar/min for safe filling, particularly of composite cylinders



B-DETECTION BASIC





GAS MEASUREMENT TECHNOLOGY

- > AERO-TEST portable breathing air tester
- > B-DETECTION MOBILE mobile online gas measurement system
- B-DETECTION BASIC stationary online gas measurement system
- > B-DETECTION PRO stationary online gas measurement system
- > with dew point sensor and higher sensor accuracy

For further accessories and more details, see our brochures "BAUER Accessories" and "B-DETECTION" and visit www.bauer-kompressoren.de



SERVICE IS A KEY COMPONENT OF OUR PHILOSOPHY.



BAUER KOMPRESSOREN is there for you all over the world. With 22 subsidiaries, over 50 regional representatives and a widely distributed service network, we offer our customers speedy contact at all times – as well as a comprehensive range of services from spare-part delivery and service agreements to a broad range of training courses. Our goal is to be in a class of our own – for both our products and our services.

- > Service agreements
- Modernisation
- > Remote maintenance
- > Spare parts
- > System rental



ACCEPTANCE AND SERVICES

MANUFACTURING IS ONLY PART OF WHAT WE DO

ISO 9001 CERTIFICATION

> BAUER assures consistent maximum product quality by applying extensive quality control measures during and after production in line with DIN EN ISO 9001.

ACCEPTANCE TESTING

- A factory acceptance test (FAT) or site acceptance test (SAT) in the presence of the customer or independent certifying body can be performed in addition to the standard BAUER final test.
- > Many BAUER compressors can also be produced in compliance with other standards, e.g. ASME, KHK, ATEX etc.

PACKING & PRESERVATION

• Our compressors are packed ex works for transport by truck or air freight. We offer appropriate packing designs tailored for shipping, transport to tropical regions or long storage periods as well as short or long-term preservation.

INSTALLATION

Professional installation is a vital basic factor in safe operation of high-pressure systems. Our global network of branches and qualified partners provides smooth, trouble-free support in planning and implementation, wherever you are.

TRAINING

To ensure your staff are always up-to-date, we provide a comprehensive range of practical training courses for our customers in our own BAUER ACADEMY, where users and operators can benefit directly from our expertise.

FOR MORE DETAILS

and more accessories, see our service brochures and visit www.bauer-kompressoren.de/en/service-support.



ARE YOU INTERESTED IN OUR PRODUCTS?

CONTACT US – WE ARE HAPPY TO PROVIDE INFORMATION AND ASSISTANCE:

BAUER KOMPRESSOREN GmbH Stäblistr. 8 81477 Munich, Germany Tel. +49 (0) 89 78049-0 Fax +49 (0) 89 78049-167 **info@bauer-kompressoren.de** www.bauer-kompressoren.de



BAUER KOMPRESSOREN POSEIDON EDITION EN N39897 11.2015 Subject to technical change without notice