

Dräger Saver CF Emergency Escape Breathing Apparatus (EEBA)

The Dräger Saver CF constant flow Emergency Escape
Breathing Apparatus allows safe, effective and uncomplicated
escape from hazardous environments. Simple to put on and
featuring practically automatic operation, this hood-based,
positive-pressure breathing device can be used with minimal
training.



WHEN TIME IS OF THE ESSENCE

In emergency situations, conditions can deteriorate rapidly. The air is suddenly filled with smoke or toxic fumes and rapid escape is the only available option. The Dräger Saver CF is highly visible and was designed to be suitable even for people with spectacles or facial hair. When opened, the Dräger Saver CF is automatically activated and begins feeding a continuous supply of breathing air. The Saver CF gives the wearer the precious additional time needed to exit the area safely.

HIGHLY VISIBLE, EVEN UNDER ADVERSE CONDITIONS

Available with either a soft bag or hard case, the Saver CF can be easily wall-mounted in strategic locations in potentially hazardous areas. Both black anti-static cases or bright orange bags feature photoluminescent panels and reflective stripes for enhanced visibility, even under low lighting conditions. The Saver CF is compact and lightweight and can be warn either as a chest bag or over the shoulder. Made from highly resistant materials, it is washable, flame retardant and allows water to drain freely.

UP TO 15 MINUTES OF LIFESAVING AIR

The Dräger Saver CF utilizes a simple, fail-safe reducer system with excellent flow characteristics, providing a consistent rate of air flow until the cylinder is completely empty. An alarm whistle sounds before the air supply is exhausted. It can be equipped with cylinders which can hold either a 10 or 15 minute supply of air. The flame-retardant hood incorporates a large visor for maximum peripheral vision.

NEW OPTIONS FOR ADDED SAFETY AND DURABILITY

The SE version includes a newly developed elastic neck seal which offers unparalleled resistance to the effects of high temperatures, ozone and diesel fumes, which are often found in places such as engine rooms. This translates to years of reliable, worry-free service, even under adverse conditions. Standard Dräger Saver CF15 units can also be retrofitted with the SE option.



Dräger Saver CF - soft bag



Dräger Saver CF - hard case

DRÄGER SAVER CF - FOR YOUR SAFE ESCAPE



LOW-MAINTENANCE PROTECTION

The Dräger Saver CF requires very little service or maintenance. A transparent window on both the soft bag and hard case lets you check the cylinder pressure gauge easily without unpacking the unit. You know the Dräger Saver CF is there for you when you need it.

CONFORMS TO RELEVANT STANDARDS AND NORMS

The Dräger Saver CF complies with EN1146 (2005), Lloyd's Register Certificate of Fire Approval and Lloyd's Register Certificate of Type Approval. It also complies with SOLAS Chapter II-2, the Marine Equipment Directive, the Pressure Equipment Directive and ISO 23269-1:2008. Anti-static versions are also suitable for use in explosive atmospheres (ATEX zone 0).









Dräger Saver CF hard case Robust storage and safe escape



Dräger Saver CF soft bag

TECHNICAL DATA

	Dräger Saver CF		
Size (H x L x D)	510 x 260 x 190 mm		
Cylinder charging pressure	200 bar		
Airflow to the hood	35-37 L/min		
Operating temperature range	-15 °C to +60 °C		
Approvals	EN1146 (2005), ISO 23269-1:2008, SOLAS Chapter II-2, the Marine Equipment Directive and the Pressure Equip-		
	ment Directive. The Dräger Saver CF anti-static is suitable for use in explosive atmospheres (ATEX zone 0).		
	CF10	CF15	
Weight (Kg) including cylinder			
Hard case	5.9 kg	6.9 kg	
Soft bag	4.2 kg	5.2 kg	
Cylinder	2L 200 bar	3L 200 bar	

ORDER INFORMATION

ORDER INFORMATION	
Dräger Saver CF – Soft bag versions	
Saver CF10	3359734
Saver CF15	3359735
Saver CF10 Anti-static	3359736
Saver CF15 Anti-static	3359737
Saver CF15 (SE)	3359742
Saver CF15 (SE) Anti-static	3359743
Dräger Saver CF – Hard case versions	
Saver CF10	3359739
Saver CF15	3357940
Saver CF15 (SE)	3359744
Accessories	
Anti-static bag for Saver CF15	3360340
Anti-static bag for Saver CF10	3360339
Anti-static bag for Saver CF15 SE	3360341
Saver waistbelt	3350396
Security tab	3350388
Wall mounting kit for cabinet	3350431
Storage cabinet	3350424
EEBA Cabinet	3351823
Safety Wash	
- 1 liter dispenser	3380164
- 1 liter refill	3380165
- 5 liter dispenser	3380166
- 5 liter refill	3380167

HEADQUARTERS

Dräger Safety AG & Co. KGaA Revalstrasse 1 23560 Lübeck, Germany

www.draeger.com

SUBSIDIARIES

AUSTRALIA

Draeger Safety Pacific Pty. Ltd. Axxess Corporate Park Unit 99, 45 Gilby Road Mt. Waverley Vic 3149 Tel +61 3 92 65 50 00 Fax +61 3 92 65 50 95

CANADA

Draeger Safety Canada Ltd. 7555 Danbro Crescent Mississauga, Ontario L5N 6P9 Tel +1 905 821 8988 Fax +1 905 821 2565

P. R. CHINA

Beijing Fortune Draeger Safety Equipment Co., Ltd. A22 Yu An Rd, B Area, Tianzhu Airport Industrial Zone, Shunyi District, Beijing 101300 Tel +86 10 80 49 80 00 Fax +86 10 80 49 80 05

FRANCE

Dräger Safety France SAS 3c route de la Fédération, BP 80141 67025 Strasbourg Cedex 1 Tel +33 3 88 40 59 29 Fax +33 3 88 40 76 67

MEXICO

Draeger Safety S.A. de C.V.
Av. Peñuelas No. 5 Bodega No. 37
Fraccionamiento Industrial
San Pedrito
Querétaro, Qro México
Tel +52 442 246-1113
Fax +52 442 246-1114

NETHERLANDS

Dräger Safety Nederland B.V. Edisonstraat 53 2700 AH Zoetermeer Tel +31 79 344 46 66 Fax +31 79 344 47 90

REP. OF SOUTH AFRICA

Dräger South Africa (Pty) Ltd. P.O.Box 68601 Bryanston 2021 Tel +27 11 465 99 59 Fax +27 11 465 69 53

SINGAPORE

Draeger Safety Asia Pte Ltd 67 Ayer Rajah Crescent #06-03 Singapore 139950 Tel +65 68 72 92 88 Fax +65 65 12 19 08

SPAIN

Dräger Safety Hispania S.A. Calle Xaudaró 5 28034 Madrid Tel +34 91 728 34 00 Fax +34 91 729 48 99

UNITED KINGDOM

Draeger Safety UK Ltd.
Blyth Riverside Business Park
Blyth, Northumberland
NE24 4RG
Tel +44 1670 352-891
Fax +44 1670 356-266

USA

Draeger Safety, Inc. 101 Technology Drive Pittsburgh, PA 15275 Tel +1 412 787 8383 Fax +1 412 787 2207