

Dräger Saver PP Emergency Escape Breathing Apperatus (EEBA)

The Saver PP constant flow Emergency Escape Breathing Apparatus allows safe, effective and uncomplicated escape from hazardous environments. Simple to put on and featuring automatic operation, this positive-pressure breathing device features an integrated full-face mask and can be used in conjunction with other safety equipment such as ear protectors or helmets.



WHEN TIME IS OF THE ESSENCE

In emergency situations, conditions can deteriorate rapidly. The air is suddenly filled with smoke or toxic fumes and rapid escape is the only available option. The Dräger Saver PP was designed for use by trained personnel. When opened, the Dräger Saver PP is automatically activated and begins feeding a continuous supply of compressed air. The Saver PP gives the wearer the precious additional time needed to exit the area safely.

HIGHLY VISIBLE, EVEN UNDER ADVERSE CONDITIONS

Available with either a soft bag or hard case, the Saver PP can be easily wall-mounted in strategic locations in potentially hazardous areas. Both black anti-static cases or bright orange bags feature photoluminescent panels and reflective stripes for enhanced visibility, even under low lighting conditions. The Saver PP is compact and lightweight and can be worn either across the chest or over the shoulder. Made from highly resistant materials, it is washable, flame retardant and allows water to drain freely.

UP TO 15 MINUTES OF LIFESAVING AIR

The Dräger Saver PP utilizes a simple, fail-safe reducer system with excellent flow characteristics, providing a consistent rate of air flow until the cylinder is completely empty. It can be equipped with cylinders which can hold either a 10 or 15 minute supply of air. The unit can easily be reset following a false alarm. Cylinders can be refilled without the need for special tools.

PANORAMA NOVA FULL-FACE MASK

The Panorama Nova full-face mask which comes with the Saver PP is another high-quality product manufactured by Dräger. This reliable full-face mask features low exhalation resistance, provides excellent peripheral vision and is self-defogging. The elastic head harness is easy to put on in and emergency and holds the mask securely in place, even under strenuous conditions. The mask can be worn together with ear protectors and helmets.



Dräger Saver PP - soft bag



Dräger Saver PP - hard case



INTEGRATED HOSE FOR CONNECTION TO EXTERNAL AIR SUPPLIES

The new Dräger PP now features an integrated air hose for connection to external mid-pressure air supplies, commonly found in muster stations and in emergency assembly areas. This feature provides the user with potentially lifesaving protection in prolonged escape situations. Hose attachment and detachment are quick, safe and easy.

LOW-MAINTENANCE, LOW COST PROTECTION

Unless otherwise specified by local regulations, the Dräger Saver PP should require little to no service or maintenance for the first 10 years. A transparent window on both the soft bag and hard case lets you check the cylinder pressure gauge easily without unpacking the unit. Checks should be performed at regulate intervals. You can then rely on the Dräger Saver PP to be there for you when you need it.

CONFORMS TO RELEVANT STANDARDS AND NORMS

The Dräger Saver PP complies with EN402 (2003), Lloyd's Register Certificate of Fire Approval and Lloyd's Register Certificate of Type Approval. It also complies with SOLAS Chapter II-2, the Marine Equipment Directive and the Pressure Equipment Directive. Anti-static versions are also suitable for use in explosive atmospheres (ATEX zone 0).







Dräger Saver PP hard case Safely escape to a muster area







Dräger Saver PP soft bag

TECHNICAL DATA

	Dräger Saver PP	
Size (H x L x D)	510 x 260 x 190 mm	
Cylinder charging pressure	200 bar	
LDV output flow L/min	500 L/min	
Operating temperature range	-15 °C to +60 °C	
Approvals	EN402 (2003), ISO 23269-1:2008, SOLAS Chapter II-2, the Marine Equipment Directive and the Pressure Equipment Directive. The Dräger Saver PP anti-static is suitable for use in explosive atmospheres (ATEX zone 0).	
	PP10	PP15
Weight (Kg) including cylinder		
Hard case	6.6 kg	7.6 kg
Soft bag	4.9 kg	_5.9 kg
Cylinder	2L 200 bar	3L 200 bar

ORDER INFORMATION

3359746
3359747
3359748
3359749
3359754
3359755
3359756
3359757
3359751
3359752
3359759
3359760
3360343
3360342
3350396
3350388
3350431
3350424
3351823
3380164
3380165
3380166
3380167

HEADQUARTERS

Dräger Safety AG & Co. KGaA Revalstrasse 1 23560 Lübeck, Germany

www.draeger.com

SUBSIDIARIES

AUSTRALIA

Draeger Safety Pacific Pty. Ltd. Axxess Corporate Park Unit 99, 45 Gilby Road Mt. Waverley Vic 3149 Tel +61 3 92 65 50 00 Fax +61 3 92 65 50 95

CANADA

Draeger Safety Canada Ltd. 7555 Danbro Crescent Mississauga, Ontario L5N 6P9 Tel +1 905 821 8988 Fax +1 905 821 2565

P. R. CHINA

Beijing Fortune Draeger Safety Equipment Co., Ltd. A22 Yu An Rd, B Area, Tianzhu Airport Industrial Zone, Shunyi District, Beijing 101300 Tel +86 10 80 49 80 00 Fax +86 10 80 49 80 05

FRANCE

Dräger Safety France SAS 3c route de la Fédération, BP 80141 67025 Strasbourg Cedex 1 Tel +33 3 88 40 59 29 Fax +33 3 88 40 76 67

MEXICO

Draeger Safety S.A. de C.V.
Av. Peñuelas No. 5 Bodega No. 37
Fraccionamiento Industrial
San Pedrito
Querétaro, Qro México
Tel +52 442 246-1113
Fax +52 442 246-1114

NETHERLANDS

Dräger Safety Nederland B.V. Edisonstraat 53 2700 AH Zoetermeer Tel +31 79 344 46 66 Fax +31 79 344 47 90

REP. OF SOUTH AFRICA

Dräger South Africa (Pty) Ltd. P.O.Box 68601 Bryanston 2021 Tel +27 11 465 99 59 Fax +27 11 465 69 53

SINGAPORE

Draeger Safety Asia Pte Ltd 67 Ayer Rajah Crescent #06-03 Singapore 139950 Tel +65 68 72 92 88 Fax +65 65 12 19 08

SPAIN

Dräger Safety Hispania S.A. Calle Xaudaró 5 28034 Madrid Tel +34 91 728 34 00 Fax +34 91 729 48 99

UNITED KINGDOM

Draeger Safety UK Ltd.
Blyth Riverside Business Park
Blyth, Northumberland
NE24 4RG
Tel +44 1670 352-891
Fax +44 1670 356-266

USA

Draeger Safety, Inc. 101 Technology Drive Pittsburgh, PA 15275 Tel +1 412 787 8383 Fax +1 412 787 2207